




FT8000-XX
STARTS IN THE 12 O'CLOCK POSITION
ROTATES COUNTER CLOCK WISE TO
THE 9 O'CLOCK POSITION




FT8000-XX-1
STARTS IN THE 12 O'CLOCK POSITION
ROTATES CLOCK WISE TO
THE 3 O'CLOCK POSITION




FT8000-XX-2
STARTS IN THE 3 O'CLOCK POSITION
ROTATES COUNTER CLOCK WISE TO
THE 12 O'CLOCK POSITION




FT8000-XX-3
STARTS IN THE 9 O'CLOCK POSITION
ROTATES CLOCK WISE TO
THE 12 O'CLOCK POSITION



FT8000-SS
XX=SS



FT8000-BK
XX=BK



FT8000-CH-BK
XX=CH-BK

